



M2M Control C 10
Remote Access & Control module

User and Programmer
Manual

INDEX

1	ABOUT M2M	5
2	ABOUT THIS MANUAL.....	6
2.1	PROGRAMMER SKILLS	6
2.2	CONVENTIONS	6
3	ABOUT THE M2M CONTROL C10 REMOTE ACCESS & CONTROL MODULE	7
3.1	BASIC NETWORK ARCHITECTURE	7
3.2	EASY PROGRAMMING	7
4	TECHNICAL SPECIFICATION	8
4.1	DIGITAL INPUT	8
4.2	DIGITAL OUTPUT.....	8
4.3	ANALOG INPUT.....	8
4.4	SERIAL PORT	8
4.5	I/O EXTENSION PORT	8
4.6	POWER SUPPLY.....	8
4.7	COMMUNICATION.....	8
4.8	MODEM.....	8
4.9	ANTENNA	9
4.10	EEPROM VARIABLES	9
5	HARDWARE SPECIFICATION	10
5.1	PHYSICAL DIMENSIONS.....	10
5.2	CONNECTORS	10
5.3	CONNECTIONS	11
6	FUNCTIONAL DESCRIPTION.....	12
6.1	COMMUNICATION MODES	12
6.2	OPERATING MODES	12
6.3	COMMUNICATION MODES.....	12
6.4	POWER-UP.....	13
6.5	ERROR HANDLING	13
6.6	END OF BASIC PROGRAM.....	13
6.7	LED INDICATORS	13
7	COMMAND LINE MODE	14
7.1	COMMAND LINE PROMPTS	14
7.2	! AND ? COMMANDS.....	14
7.2.1	Write to Outputs	14
7.2.2	Write to Variables	15
7.2.3	Read Input or Output status	15
7.2.4	Read internal BASIC variables	15
7.2.5	! and ? commands via SMS.....	15
7.3	SET COMMANDS	16
7.3.1	SET ID	16
7.3.2	SET EVENTS.....	16
7.3.3	SET USERIO ON/OFF.....	17
7.3.4	SET PIN xxxx	17
7.3.5	SET PASS	17
7.3.6	SET GPRS ON / OFF	17

7.3.7	SET APN xxxxxxxxxxxxxxxxxxxx (GPRS ONLY).....	17
7.3.8	SET GPRSUSER xxxxxxxxxxxxxxxx (GPRS ONLY).....	17
7.3.9	SET GPRSPASS xxxxxxxxxxxxxxxx (GPRS ONLY).....	17
7.3.10	SET MAILUSER xxxxxxxxxxxxxxxx (GPRS ONLY).....	17
7.3.11	SET MAILPASS xxxxxxxxxxxxxxxx (GPRS ONLY).....	17
7.3.12	SET HOST xxxxxxxxxxxxxxxx (max 15 char.) (GPRS ONLY).....	18
7.3.13	SET PORT xxxxx (GPRS ONLY).....	18
7.3.14	SET SMTP xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx (GPRS ONLY).....	18
7.3.15	SET FROM xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx (GPRS ONLY).....	18
7.3.16	SET MAIL1..5 xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx (GPRS ONLY).....	18
7.3.17	SET SMS1..10 xxxxxxxxxxxxxxxx (max 15 char.) (For GSM only).....	18
7.3.18	SET UPDATE ON.....	18
7.4	VERBOSE COMMANDS	19
7.5	STATUS.....	20
7.6	CONFIG.....	20
8	EXECUTION MODE.....	21
8.1	INSTRUCTIONS.....	21
8.2	REMOTE USE OF ! AND ? COMMANDS DURING EXECUTION.....	21
8.3	PREDEFINED VARIABLES	22
8.3.1	Operands.....	22
8.4	DELIMITERS	22
8.5	PROGRAM EXAMPLE.....	23
9	LET'S START.....	24
9.1	1ST STEP, FIRST PROGRAM.....	24
9.2	ABOUT PROGRAMMING IN BASIC.....	25
10	SAMPLE BASIC PROGRAMS.....	26
11	SCHEMATIC DIAGRAM.....	32
11.1	M2M CONTROL C10 ACCESS & CONTROL MODULE.....	32
12	BASIC TUTORIAL.....	33
12.1	PROGRAMMING IN BASIC	33
12.2	TO START OFF, WHAT IS PROGRAMMING ANYWAY?.....	33
12.3	VARIABLES - DOING SOMETHING WITH INFORMATION	34
12.4	OPERANDS – DOING SOME CALCULATIONS.....	35
12.5	DELIMITERS – SEPARATING DATA	35
12.6	AT FIRST – DOING SOMETHING TO START WITH	35
12.7	GOTO - DOING SOMETHING MORE THAN ONCE.....	36
12.8	GOSUB - DOING SOME JUMP TO A PROGRAM PART, DO SOMETHING AND RETURN.....	36
12.9	IF...THEN...ELSE - ADDING INTELLIGENCE TO YOUR PROGRAM.....	38
12.10	IF...AND/OR... THEN...ELSE - ADDING MORE INTELLIGENCE TO YOUR PROGRAM	38
12.11	MORE ADVANCE PROGRAMMING.....	38
12.12	FOR...TO...NEXT - ADDING LOOPS TO YOUR PROGRAM	39
12.13	PRINT, SEND, LOG, MAIL AND SMS - INFORMING THE OUTSIDE WORLD	39
12.14	REM - ADDING REMARKS TO YOUR PROGRAM	40
12.15	FINAL - DOING IT MORE COMPLEX.....	40
12.16	COMMAND LINE MODE - DOING SOMETHING OUTSIDE YOUR PROGRAM	41
13	APPENDIX.....	42
13.1	GSM MODEM STATES	42
13.2	CONFIGURATION HINTS.....	45

1 About M2M

M2M means "machine-to-machine" or "man-to-machine" and is to do with the remote monitoring and control of machines.

We offer total M2M system solutions to the market under the brand M2M Control. We provide the means for connecting remote devices to Internet/intranet, enterprise IT systems and other proprietary systems - whether those devices themselves are moving or static.

By doing so, industrial processes can be automated. Widely dispersed machines or apparatus can be brought together into an integrated whole and a wide variety of new services can be created.

Using Wireless M2M communications, a machine can be installed virtually anywhere but still be connected to a support centre to signal performance or need for service. M2M data will improve the service quality and reduce operating costs. Many application areas can be improved using M2M. Assets can be tracked and guarded, refrigerated lorries can be monitored, security alarms can be made more effective, stock control improved. These are just a few examples.

Wireless M2M communications technology is here and will play an indispensable role in reducing costs across all business sectors.

"By 2007, there will be between 100 million and 200 million machine-to-machine connections worldwide that use wireless mobile networks or Internet.

For more details please visit:
www.m2mcontrol.de



2 About this manual

This manual introduces the free programmable generic
M2M Control C10 Remote Access & Control module.

On the CD in the back of this manual, you will find documentation and sample source files:

- BASIC sample programs.
- This manual published in Acrobat PDF format ver. 3.0.

This manual explains: installation, programming and configuration of the *M2M Control C10* remote control module, as well as the BASIC language.

2.1 Programmer skills

The programmer / engineer have to poses the basic understanding of:

- BASIC programming language
- Communication techniques of GSM / GPRS

2.2 Conventions

Edit Bold Arial font indicates the Command line text that should be typed

Italics Bold Courier Italics indicates the returned text a response to a command

“...” Names like file names, email addresses, web-sites, etc are within quotes.

<.> Buttons.

3 About the *M2M Control C10* Remote Access & Control module

The *M2M Control C10* is a generic remote access & control module for self-programming. This module is equipped with a modem for using:


1. GSM communication.
or
2. GPRS communication.

This manual explains the hardware and programming of the module.

The term “Remote control” and “Remote access” are used for applications needed for remote management and covers functions such as: control, monitoring, configuration, diagnostics, etc. by means of a communication link.

3.1 Basic network architecture

The *M2M Control C10* Remote Access & Control module is a network module for use in a GSM/GPRS network designed for easy monitoring and control. This ease of use is achieved by means of a simple BASIC interpreter and easy (remote) command line instructions. This makes the *M2M Control C10* easy to program by anyone with a little understanding of the BASIC programming language.



3.2 Easy programming

The *M2M Control C10* Remote Access & Control module has an embedded BASIC interpreter for easy programming. Simple BASIC instructions give the programmer instant control over Inputs and Output, sending SMS's or other messages. This manual will explain the use of the BASIC programming language in detail in chapter 12, BASIC Tutorial. In chapter 10 you will find many programming examples.

4 Technical specification

The *M2M Control C10* is a generic module with 1 digital input and 1 analog input as well as 1 digital output. The module is for simple registration of an alarm or measuring levels.

4.1 Digital Input

1 x Digital input, this input is galvanic isolated from the power supply by an OPTO coupler. Use **external 24V**dc or ac as input voltage, 0 Volt results in an inactive state of the input, 24V \pm 10% is active, and the current through the input contacts is 2.5 mA.

This input has one variable: **DI1**, Value = 0 – 1
and

one variable as a counter to count input pulses: **DP1**, Value = 0 – 32767

4.2 Digital Output

1 x Digital output, this output is a RELAY volt free contact (max 24Vac or dc / 0.2 Amp). This output has one software variable for the state: **DO1**, Value = 1 or 0 (1 = Closed)

4.3 Analog Input

1 x Analog input for the use if 4-20mA sensors
This input has a software variable for the state: **AI1**,
Value = 0 – 1023 (0= 0mA, 200= 4mA, 1000 = 20mA)

4.4 Serial port

1 x RS232e Serial communication port for console, use XON/XOFF handshake.

4.5 I/O extension port

1 x I²C interface (for use of extension module, like data logger).

4.6 Power supply

24Vac or dc, 1VA during normal operation, 3VA during transmission burst.
Typical current consumption <40mA (no transmission)

4.7 Communication

GSM/GPRS modem with internal antenna or external antenna.

4.8 Modem

GSM/GPRS: TELIT GM862 PCS

4.9 Antenna

Coaxial SMA connector.

4.10 EEPROM variables

Cell endurance of the EEPROM variables (**EEA ... EEJ**) is typical one million writes. Minimum 100.000.

Please calculate the life cycle of your module carefully!

Sample: To store a value in the **EEA** once every 5 minutes.

This is 12 per hour, 288 times a day, and 104832 per year. With this write frequency you arrive into the critical zone within one year.


Writing to EEPROM should NOT exceed ONCE per HOUR!

5 Hardware specification

The *M2M Control C10* is a generic module with 1 digital and 1 analog input as well as 1 digital outputs.


The module form factor is based on the M36 DIN-rail enclosure standard.

5.1 Physical dimensions



All modules M36 Din-rail
Depth from rail = 60mm

5.2 Connectors



Use the following plugs:
 \24Vac power: Phoenix 5 mm, 2pin
 MSTBW 2,5/ 2-ST

I/O Phoenix 3,8 mm, 6pin
 MCVW 1,5/6-ST-3,81

Console: 9 pin D-connector
 Female


I²C: RJ12 6 pin

6 Functional description

6.1 Communication modes

The *M2M Control C10* Remote Access & Control module can communicate with a PC or application through 2 different paths

- a- Local via RS232 console port
- b- Remote via GSM/GPRS mobile network, direct via terminal or via SMS



6.2 Operating modes

The *M2M Control C10* Control module can run in two modes:

1. Command line mode
This mode is for the operator and enables: testing, programming and configuration of the *M2M Control C10* Control module, either LOCAL or from REMOTE.
2. Execution mode
This mode is a continuous program execution and enables: I/O manipulation under BASIC program control, automatic sending messages as well as handling of received messages.

6.3 Communication modes

The *M2M Control C10_GSM / GPRS* version (version 2.0) can communicate in 2 ways; Using GSM or GPRS. This mode is configurable with SET GPRS ON / OFF(see SET commands).

Functional difference:

FUNCTION:	GSM / GPRS
SMS	X
E-mail	X
SEND	X

6.4 Power-up

The *M2M Control C10* Control module will start after power-up in the following Operating Mode:

1. Command line mode, if Console is connected to the *M2M Control C10*
2. Execution mode, if NO Console is connected to the *M2M Control C10*

ATTENTION: Removing the RS232 console connector will switch the module automatically into Execution mode!

6.5 Error handling

1. During Execution mode **without** a **Console** connected, the *M2M Control C10* Control module will continue to RUN at all times, therefore while encountering a program error the BASIC program will reset and start at the first program line.
2. During Execution mode **with** a **Console** connected, the *M2M Control C10* Control module will STOP to RUN and show the error text.


6.6 End of BASIC Program

During Execution mode **without** a **Console** connected, the *M2M Control C10* Control module will reset and start at the first program line after encountering:


- END instruction,
- or
- last BASIC program line without a RETURN or GOTO instruction.

6.7 LED Indicators

The left LED adjacent to the power connector indicates Power OK. The two LEDs on the right site of the module indicate Remote link active (Green) and Command line mode disabled (no program execution) the latter is RED and OFF during normal operation.



The LED behind the window in the label is a GSM indicator.



The GSM Link LED

LED status	Device Status
Permanent OFF	Device OFF
Fast blinking (period 1s, 0.5s ON)	Net search / Not registerd / Turning OFF
Slow blinging (period 3s, 0.3s ON)	Registerd full service
Permanently ON	A call is active

7 Command line mode

In the command line mode the user can do the following:

- **LOAD** a basic program into the module, max. 4096 char. program text.
- **LIST** the internal basic program.
- **RUN** the internal basic program starting at the first line (switch to "Execution mode").
- **STOP** the internal basic program (switch to "Command line mode").
- **CONTInue** execution at the position the program was stopped.
- **HELP** shows initial instructions.
- **STEP** 1 line used for debugging.
- **RESET** go to first valid line.
- **<Enter>** repeat last command.
- **STATUS** shows general status.
- **CONFIG** shows configuration.
- **! and ? commands** to read and write I/O and variables, see chapter 7.2.
- **GET commands** to get configuration, see chapter 7.3.
- **SET commands** to set configuration, see chapter 7.4.
- **GET xxxxx** Log commands, see M2M Control Data logger manual
- **Verbose commands** to follow network messages, see chapter 7.4.

RUN changes the operating mode from "Command line mode" to "Execution mode"

STOP changes the operating mode from "Execution mode" to "Command line mode"

ATTENTION: Commands are NOT case sensitive load or Load is OK

7.1 Command line prompts

- > Normal prompt
- > Print prompt
- >> Step prompt
- L> Data from Logger

7.2 ! and ? commands

In the "Command line mode" the operator can type the commands !xx and ?xx to create a direct I/O change or read and write to BASIC variables.

This can be done from a PC connected to the RS232 Console port or from a Remote location either way gives the same results.

7.2.1 Write to Outputs

BEWARE!!! Please know what the output does. It can harm persons or machine parts to switch ON the output without a thorough understanding of its consequences!

Type the following commands:

- !DO1=1** Sets Digital output1 ON
- !DO1=0** Sets Digital output1 OFF

7.2.2 Write to Variables

For debugging purpose it is very handy to have direct control over internal BASIC variables. You can write any variable using the ! – command.

You can write to the following variables: **A...Z, TM1...TM8, DO1, DP1, EEA...EEJ**

!A=10 Sets BASIC variable A to 10
!A=10, B=25 Sets BASIC variable A to 10 and B to 25

ATTENTION!

All command line commands starting with **!** are **disabled** during **execution** mode, unless you **SET USERIO ON**.

The **!** command can be used from the Console, Dail-up or Direct GPRS link.

Using **Mobitex** or **SMS** you need to add the password for example, **admin!DO1=1,DO2=0,DO3=1**

7.2.3 Read Input or Output status

Type the following commands:

Digital I/O

?DI1 reads DI1, returns: **?DI1=0** or **?DI1=1**

?DI1,DO1 reads DI1 and DO1, returns e.g.: **?DI1=0,DO1=1**

Analog I/O

?AI1 reads AI1, returns e.g. : **?AI1=460**

Easy Way!

The command line **STATUS** command will give you an overview of all I/O status at once!

7.2.4 Read internal BASIC variables

For debugging purpose you can use the PRINT statement in your program or use the command line ? – command to get the value of internal BASIC variables.

You can read to the following variables: **A...Z, TM1...TM8, DI1, DO1, AI1, DP1, EEA...EEJ**

?A reads BASIC variable A and returns e.g.: **?A=10**

?TM2 reads BASIC Timer2 status and returns e.g.: **?TM2=-1**

?DP1 reads Input1 Counter status and returns e.g.: **?DP1=2345**

7.2.5 ! and ? commands via SMS

The Write (!) and Read (?) commands can be sent to the module by SMS. In case of a Read request the module will return an SMS message. Please be aware that it can take a while to receive an SMS message. This is stongly depending on the network availability.

Using SMS, you need to add the password, for example **admin!DO1=1**

7.3 GET commands

For reading date and time:

7.3.1 GET DATE

Fetch date

7.3.2 GET TIME

Fetch Time

7.4 SET commands

SET command is used for configuration of the module once. All SET command entries are stored in EEPROM and non-volatile.

7.4.1 SET DATE

Set date for example SET DATE MON 01-01-07

7.4.2 SET TIME

Fetch Time for example SET TIME 00:00:00

ATTENTION: Please realize that the C100 will loose date&time data after power down.

7.4.3 SET ID xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx

Module ID string will be used in e-mail. This ID is maximum 30 characters and available as static Basic variable ID.

7.4.4 SET EVENTS


SET EVENTS ON (GPRS only)

SET EVENTS OFF (GPRS only)

EVENTS ON is used for REAL-TIME monitoring with a remote application. This gives an instant update of the I/O status without the need of polling. It works with a real-time GPRS link only. In case **EVENTS** is set to **ON** the event is sent as an auto response like a read command with a leading #, e.g. #DI1=0.

ATTENTION!

Events are send for the Digital I/O changes only.



EVENT: Contact Closes, Message is send to Remote Server #DI1=1
 EVENT: Contact Opens, Message is send to Remote Server #DI1=0

To monitor changes of the **analog input value** use the **PRINT** or **SEND** command in your program to POLL the variable.

7.4.5 SET USERIO ON/OFF

USERIO On will make it possible to overrule an Output or Basic variable while executing a basic program. E.g. from local console or remote connection !DO1=1 will set DO1 to ON while the program is running.

ATTENTION: Please be aware that program execution can reverse this action.

For commands passed by SMS, you need to add the PASSWORD like:

Admin!DO1=1

7.4.6 SET PIN xxxx

4 digit PIN for SIM card is stored in EEPROM memory (PIN is not shown in CONFIG)

ATTENTION: PIN is not shown in Config screen!

7.4.7 SET PASS xxxxxxxxxxxx

Enter password for Command Line protection (maximum 10 char.)

ATTENTION: Password is not shown in Config screen!

7.4.8 SET TCP ON / OFF

With this setting the GPRS communication mode is set ON or OFF

7.4.9 SET APN xxxxxxxxxxxxxxxxxxxx (GPRS ONLY)

This is the Access Point Name for Internet access (maximum 20 char.)

7.4.10 SET TCPUSER xxxxxxxxxxxxxxxx (GPRS ONLY)

This is the user name for Internet access (maximum 15 char.)

7.4.11 SET TCPPASS xxxxxxxxxxxxxxxx (GPRS ONLY)

This is the password for Internet access (maximum 15 char.)

7.4.12 SET MAILUSER xxxxxxxxxxxxxxxx (GPRS ONLY)

This is the mail user name for Mail Server access (maximum 15 char.)

7.4.13 SET MAILPASS xxxxxxxxxxxxxxxx (GPRS ONLY)

This is the password for Mail Server access (maximum 15 char.)

7.4.14 SET MAILSUBJECTxxxxxxxxxxxxxxxx (GPRS ONLY)

Sample: Email from C100 device (maximum 30 char.)

7.4.15 SET HOST xxxxxxxxxxxxxxxx (max 15 char.) (GPRS ONLY)

With this command the remote host number is set, this adres is used for the SEND command.

- For GPRS HOST = IP address of host OR HOST NAME WWW..... (MAXIMUM 30 CHAR.)
- For GPRS HOST = 0 No HOST connection used

7.4.16 SET PORT xxxxx (GPRS ONLY)

This is the IP port of the Host (maximum 65535.)

- For GPRS PORT = 0 No HOST connection used

7.4.17 SET SMTP xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx (GPRS ONLY)

This is the Mail Server Name or IP number for sending an email (maximum 30 char.)

7.4.18 SET FROM xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx (GPRS ONLY)

This is the Sender email address for sending an email (maximum 30 char.)

The M2M Control module can not receive email. Use any usefull address like mymodule@myplace.com.

7.4.19 SET MAIL1..5 xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx (GPRS ONLY)

With this command the email address are stored in register 1 to 5. (max 30 char.)

Use the – sign to clear number

Example: SET MAIL1 m2m@m2mcontrol.de, address is stored in first register

Use the **CONFIG** command to see all stored Addresses on your console screen.

7.4.20 SET SMS1..10 xxxxxxxxxxxxxxxx (max 15 char.) (For GSM only)

With this command the SMS numbers are stored in register 1 to 10.

Use the – sign to clear number

Example: SET SMS1 +3162345678, number +3162345678 is stored in first register

Use the **CONFIG** command to see all stored numbers on your console screen.

7.4.21 SET UPDATE ON

Used for updating the firmware of the module.

ATTENTION: Any change of settings related to GPRS needs a reset of the module, this can be done by typing SET GPRS ON.

7.5 VERBOSE commands

For diagnostic purposes only:

The following commands are for the experienced engineer only and are worked from the Console port only.

For GSM/GPRS

MODEMVERBOSE X

X = 0 verbose state is turned off


X = 1 shows modem states: See appendix (chapter 13) for modem state information

7.6 STATUS

The **STATUS** command is very usefull and shows general status of the module.

First all Inputs and Outputs values

- DI1
- DO1
- AI1
- Mobile net operator
- RSSI signal strength & quality
- RSSI: 0 is NO signal
- RSSI: 1...5 is 1 bar
- RSSI: 6...9 is 2 bars
- RSSI: 10...14 is 3 bars
- RSSI: 15...31 is 4 bars
- RSSI: 99 not detected signal strength
- Basic program size
- Last error: Basic program error




```

iTECHnologies IO_10_GSM,version 2.0B
>status
IO_10_GSM,version 2.0B
DI1=0
DO1=0
AI1=1
Operator: NL KPN Mobile BU
RSSI: 19
  BASIC PROGRAM
Program size: 38 bytes, 0% used
Last error: None
>_
  
```


7.7 CONFIG

The **CONFIG** command is very usefull and shows configuration of the module.



```

iTECHnologies IO_10_GSM,version 2.0B
>config
ID String: Ysselstaete
UserIO: OFF
GPRS: OFF
APN: internet
GPRS user: user
SMTP: mail.server.com
Mail user: user
From: IO_100@hitechnologies.nl
Events: OFF
Host: 0
SMS Number 1: -
SMS Number 2: -
SMS Number 3: -
SMS Number 4: -
SMS Number 5: -
SMS Number 6: -
SMS Number 7: -
SMS Number 8: -
SMS Number 9: -
SMS Number 10: -
>_
  
```



```

iTECHnologies IO_10_GSM,version 2.0B
>config
ID String: Ysselstaete
UserIO: OFF
GPRS: ON
APN: internet
GPRS user: user
SMTP: mail.server.com
Mail user: user
From: IO_100@hitechnologies.nl
Events: OFF
Host: 0
Mail address 1: -
Mail address 2: -
Mail address 3: -
Mail address 4: -
Mail address 5: -
>_
  
```

Configuration info: SMS phone book or E-mail addresses

8 Execution mode

In the execution mode the processor will execute a BASIC program line by line, which is loaded in FLASH memory. The BASIC interpreter can perform the following instructions:

8.1 Instructions

- **PRINT ...** sends output to the console port, max 80 char.
- **IF ... THEN ... ELSE** conditional instruction
- **AND OR** conditional instruction used in combination with IF...THEN
- **GOTO** jump instruction
- **FOR ... TO ... NEXT** loop instruction
- **GOSUB ... RETURN** jump to sub-routine, returns in next line
- **SEND ...** sends output to the remote receiver, max. 59 char. (GPRS only)
- **SMS x, ...** sends output as SMS, max 80 char
- **MAIL x, ...** sends output as E-Mail, max 80 char
- **REM** used to enter remarks
- **END** terminate program execution, works with connected console only
- **LOG...** sends output to optional data logger, max 50 char (like print..)

ATTENTION: Instructions are NOT case sensitive print or Print is OK

8.2 Remote use of ! and ? commands during execution

The user can influence the module in two ways:

1. Direct terminal connection via GSM Dial-in or GPRS host command session
This mode is like a direct console connection. ?-commands can be executed during execution mode, !-commands after program STOP only.

ATTENTION: Please realize that while you SET an Output or Variable, that after re-start of program execution the I/O or variables might change right back, you need to understand the application.

2. Send a SMS to the module
With a SMS message you can do everything that fits in ONE message.
You need to put the valid PASSWORD as PREFIX, e.g. **admin!DO1=1**
This command will set Digital Output1 to ON instantly with no need to STOP the BASIC program first.

The SMS command: **admin?DO1,DI1,AI1** will result in receiving the following SMS:
?DO1=1,DI1=0,AI1=123

Long text outputs of STATUS and CONFIG are not supported by SMS, this would result in several SMS messages and is not very practical. Please use the Dial-up method for STATUS and CONFIG.

ATTENTION: Please realize that while you SET an Output or Variable, the BASIC program is still executed and might change your setting right back, you need to understand the application.

8.3 Predefined variables

The interpreter has the following pre-defined variables:

A ... Z	integer, -32768+32767
EEA ... EEJ	NON VOLATILE integer, -32768+32767
ID	ID of maximum 30 characters READ ONLY, see SET ID for details
DI1	for the digital input STATUS, ATTENTION! DI1 is a READ ONLY variable the value is 1 or 0
DP1	Counter for the digital input, the value is 1...32767
DO1	for the digital output STATUS, the value is 1 or 0
AI1	for the analog input, value = 0 -1023
TM1 ... TM8	for 100 milliseconds timer, ATTENTION! if read, this variable returns 0, 1 or -1 0 = Timer EXPIRED, after once read this value becomes -1 1 = Timer is RUNNING -1 = Timer is IDLE Timer SET value is max. 32767 this equals 3276,7 seconds
SEC	contains the number of seconds since the last minute lapse (0-59)
MIN	contains the number of minutes since the last hour lapse (0-59)
HRS	contains the number of hours since midnight (0-23)
DAY	contains the day of the month (1-31)
WDAY	contains the day of the week (0-6, 0=Sunday)
MTH	contains the month (1-12)
YRS	contains the number of years since 2000 (0-255)
TRE	(Time REsult) is 0 when the <i>M2M Control C100</i> thinks it has a valid time.
CTSM	Clear To SMs must be 1 before using the SMS command
CTSE	Clear To SEnd to see whether there is a working host link (0=no link available, 1=link available)
CTM	Clear To Mail must be 1 before using the MAIL command
MRE	Mail REsult, equals 0=ok, 1 indicates error, the mail was sent
SMRE	SMs REsult, 0=ok, 1 indicates error, SMS was not sent
SERE	SEnd REsult, 0=ok, 1 indicates error, SEND message was not sent

See chapter 12 for more details on the use of variables.

8.3.1 Operands

The interpreter can manipulate variables with the following operands:

+ - * ^ / % = > < <> & |

See chapter 12.4 for more details on the use of operands.

8.4 Delimiters

The interpreter can handle the following delimiters:

; : () ,

See chapter 12.5 for more details on the use of delimiters.

8.5 Program example

```
PRINT "This is an example of a BASIC program."  
REM version 1.0  
A=1:B=5:X=0  
TM1=50  
TM2=0  
100 IF DI1 THEN GOSUB 200  
IF AI1<200 then DO1=1  
IF TM1=0 THEN GOSUB 300  
IF TM2<1 THEN DO1=0 ELSE DO1=1  
GOTO 100  
  
200 PRINT "X=";X,"A=";A,"B=";B  
FOR T=1 TO 5  
  X=X+T  
  A=A*B  
  PRINT "X=";X,"A=";A,"B=";B  
NEXT  
RETURN  
  
300  
  TM1=50  
  TM2=10  
RETURN  
#
```

9 Let's start


9.1 1st step, first program

Let's start to load the first program.

Use any text editor to write a program, always save as plain ASCII text.

In case you use a word processor program like MS WORD, than save as .TXT text file.

Step1 Connect the *M2M Control C10* as follows:



Plug *M2M Control C10* connectors, 24 Volt and PC
Connect 24V trough a switch to pin 5(+) and 6(-)
Connect 24V trough a 24V Lamp to pin 1 and 2

Step2 Power up all equipment

Step 3 Write the following program using a text editor like Notepad and save as text file:

```
TM1=10
10 IF TM1=0 THEN GOSUB 100
GOTO 10
100 TM1=10
IF DO1=0 THEN DO1=1 ELSE DO1=0
RETURN
#
```

Step 4 Start HyperTerminal with the following configuration:

- Baudrate 9600
- 8 data bits, 1 stop bit, no parity, Hardware handshake XON/XOFF
- Set VT100, Enable "Append Line feeds to incoming line ends" in ASCII settings
- Press on <Enter> this should give a response with name, version and password

Step 5 Enter password: **admin** (factory default)



Step 6 Load the basic program into the module

Type **LOAD**

Select Transfer, Send Text file, Select File

10 Sample BASIC programs

Below are some comparisons between a standard schematic and the software derivative.



First program

This program switches ON the output with a few seconds in between. At A=500 the output switched OFF or ON depending on the state.

The timing is produced by the loop of a hundred times returning to line 30 and incrementing A.

```

10 REM this is the first demonstration program
20 PRINT "Hello world, this is my first program"
DO1=0
30 A=A+1
PRINT A
IF A=100 THEN DO1=1
IF A=200 THEN DO1=0:A=0
GOTO 30
#
  
```

Second program

This program consist of two small demonstrations of the use of the IF...THEN statement

```

10 PRINT "2nd program demo of IF...ELSE"
20 A=0:DO1=0
30 PRINT "DI1=";DI1,"A=";A
IF DI1=1 THEN A=10:DO1=1 ELSE A=0:DO1=0
GOTO 30
#
  
```

```
PRINT "2nd program demo of IF...AND..."
PRINT "and IF...OR..."
20 DO1=0:DO4=0
30 IF DI1=1 AND DI2=1 THEN DO1=1 ELSE DO1=0
GOTO 30
#
```

Third program

This program demonstrates the use of sub-routines.
With DI1 you trigger an output pulse of 5 seconds.

```
10 PRINT "3rd program demo of sub-routines"
REM PULSE OUTPUT, START WITH DI1
20 TM1=0
30 IF DI1=1 THEN GOSUB 100
IF TM1<1 THEN DO1=0
GOTO 30

100 IF A=0 THEN TM1=50
REM TM1 = 50 equals 5 seconds
DO1=1
RETURN
#
```

Fourth program

This program creates output pulses with low frequency or high frequency on DO1. You switch between the two frequencies with DI1.

This demonstration program comes in two parts.

4a - using a FOR...NEXT loop

4b - using timer TM1

```
REM This is a demonstration program
10 PRINT "Program 4th demo of FOR...NEXT"
20 IF DI1=1 AND A=1 THEN A=0 ELSE A=1
IF A=1 THEN GOSUB 100 ELSE GOSUB 200
GOTO 20

100 DO1=1
FOR B=1 TO 10
PRINT "B=";B
IF A=5 THEN DO1=0
NEXT
DO1=0
RETURN

200 DO1=1
FOR B=1 TO 50
PRINT "B=";B
IF B=25 THEN DO1=0
NEXT
RETURN
#
```

After the # (end of program sign) you can type any text.
This program demonstrates the working of a FOR...NEXT loop.

```
PRINT "4b as program 4a with timer"
A=0
```

```
20 IF DI1=1 AND A=10 THEN A=50 ELSE A=10
GOSUB 100
GOTO 20
100 PRINT "A=";A
IF TM1=0 THEN TM1=A:GOSUB 200
RETURN

200
IF DO1=1 THEN DO1=0 ELSE DO1=1
RETURN
#
```

Fifth program

This program demonstrates all kinds of calculation tricks.

```
10 PRINT "5th program demo of calculation"
20 A=1:B=2:C=3:D=4:E=5:F=20
PRINT "A=";A,"B=";B,"C=";C,"D=";D,"E=";E,"F=";F
A=B+C
PRINT "A=B+C   A=";A,"B=";B,"C=";C
A=E-C
PRINT "A=E-C   A=";A,"E=";E,"C=";C
A=B*C
PRINT "A=B*C   A=";A,"B=";B,"C=";C
A=F/C
PRINT "A=F/C   A=";A,"F=";F,"C=";C
A=F%C
PRINT "A=F%C   A=";A,"F=";F,"C=";C
A=B^D
PRINT "A=B^D   A=";A,"B=";B,"D=";D
A=(B+C)*(E+F)
PRINT "A=(B+C)*(E+F)   A=";A,"B=";B,"C=";C,"E=";E,"F=";F
#
```

Sixth program

This program demonstrates the STEP function.
Do not use RUN but use STEP.

```
10 PRINT "6th program demo STEP function"
20 PRINT "this is line 2"
PRINT "this is line 3"
PRINT "this is line 4"
PRINT "this is line 5"
PRINT "this is line 6"
PRINT "this is line 7"
PRINT "this is line 8"
PRINT "this is line 9"
PRINT "this is line 10"
GOSUB 100
GOTO 20

REM   SUB ROUTINES
100 PRINT "this is line 15"
GOSUB 200
RETURN
200 PRINT "this is line 18"
RETURN
#
```

Seventh program

This program demonstrates the use of a timer by calculating minutes, hours and days.

```
10 PRINT "7th program demo timer function"
20 REM set timer to 600 this equals 1 minute
30 TM1=600:M=0:U=0:D=0
40 IF TM1=0 THEN GOSUB 100
GOTO 40
REM SUB ROUTINES
100 TM1=600
M=M+1
IF M=60 THEN M=0:U=U+1
IF U=24 THEN U=0:D=D+1
IF D=7 THEN D=0
PRINT "M=";M," U=";U," D=";D
RETURN
#
```

Eighth program

This program demonstrates the use of the analog inputs.
Use a potentiometer or current source for testing.

```
10 PRINT "8th program, demo of analog input"
20 print "AI1=";AI1
GOTO 20
#
```

ATTENTION!

Analog input of the M2M Control C 10 is a current loop input range from 0-20 mA. A value <4 indicates a defective sensor.

Ninth program

This program demonstrates sending a SMS.
Please be sure you SET SMS telephone numbers.

```
10 PRINT "9th program, demo of SMS message"
20 IF DI1=1 AND A=0 THEN a=1:SMS 1,"This is a test"
30 IF DI1=0 THEN A=0
GOTO 20
#
```

Tenth program

This program demonstrates sending a XML formatted output.

```
REM this is a demonstration program for Row data and XML output
10 REM START OF LOOP
REM PROBE SAMPLE ONLY
L=AI1/10: REM 2-40mA SENSOR FULL SCALE = 100%
IF DI1=1 AND A=0 THEN GOSUB 100
IF DI1=0 THEN A=1
GOTO 10

100 SEND "<!-- File Name: XML_Demo.xml -->"
GOSUB 500
SEND "<?xml-stylesheet type='text/xsl' href='XML_Demo.xsl'?>"
GOSUB 500
SEND "<IO100><DI><DI1>";DI1;"</DI1></DI><AI><AI1>";AI1;"</AI1></AI>"
GOSUB 500
SEND "<Level>";L;"</Level></IO100>"
RETURN

500 REM WAIT FOR MODEM READY TO SEND NEXT DATA BLOCK
rem TM1=100
510 IF CTSE=1 THEN RETURN: REM TM1=0:RETURN
REM IF TM1=0 THEN GOTO 10: REM MODEM FAULT
GOTO 510
RETURN
#
```

Example of the XML output file

```
<!-- File Name: XML_Demo.xml --><?xml-stylesheet type=text/xsl
href=XML_Demo.xsl?>
<IO100>
  <DI>
    <DI1>0</DI1>
  </DI>
  <AI>
    <AI1>1</AI1>
  </AI>
  <Level>0</Level>
</IO100>
```

Eleventh program

This program demonstrates the use of the CTM and MRE variables.

```
print "CTM=";ctm, "Clear to mail"
print "MRE=";mre, "Mail result"

rem Wait until modem is ready to send mail
10 if ctm=0 then goto 10

rem Send mail
mail 1,"this is a test mail"


rem Wait until modem is finished sending mail
20 if ctm=0 then goto 20

rem Print the mailed result
print "MRE=";mre

rem endless loop
30 goto 30
```

11 Schematic diagram

11.1 M2M Control C10 Access & Control Module



12 BASIC Tutorial

12.1 PROGRAMMING IN BASIC

BASIC (Beginners All purpose Symbolic Instruction Code) was created in the 1960's as an easy to learn programming language for computers. Because of BASIC's simple format and because it was an interpreted language that gave the programmer instant feedback, it became the most popular programming language when microcomputers made their debut.

The "M2M Control C10 Remote Access & Control Module" has an embedded BASIC Interpreter with a limited command set. The M2M Control C10 does not support string manipulation. The BASIC interpreter has new non standard commands like the instruction to send a SMS message.

Perhaps you found your way here because you're new to programming and would like to start off by learning BASIC. This tutorial will cover important points in detail with sufficient explanation for programming the M2M Control C10 only. This tutorial introduces the first principles of BASIC, but doesn't provide a thorough description of all language features. For more information on the full language and command set, we advice you to refer to standard teaching books.

A BASIC program is built up line by line out of combinations of the simplest software parts. Once you learn what these software parts are and how they're used and with some work and imagination it can take you almost anywhere. Programming is (simply put) the laying out of simple steps to solve a problem and in a way that an M2M Control C10 can understand. This is a little bit like teaching a person. These steps must be arranged in the correct order.

Just remember that most programming mistakes are due to programming the wrong sequence, for example you have an instruction to set an OUTPUT to ON and the next instruction sets it (unnoticed) back to OFF, or simply because of spelling mistakes for example: D01 instead of DO1.

The M2M Control C10 has some simple built in diagnostics help functions, like the **STEP** command. This is a way to go line by line through your program.

12.2 TO START OFF, what is programming anyway?

How do you write a program? Basically you write commands. These are special keywords (instructions) telling the processor inside the M2M Control C10 to do something. For example, one of the simplest commands in BASIC is the PRINT statement. It goes like this:

```
PRINT "Hello!"
```

When you type this one line program using a text editor, you'll need to store this program with the **LOAD** command in non-volatile memory inside the M2M Control C10 which can interpret this BASIC program and RUN it. Running a program means executing the commands line by line. In this case there is only one line and you'll see the word **Hello!** printed on the terminal screen. We call PRINT a "statement" or "command", PRINT sends out text on the screen. This is called OUTPUT.

A program in its simplest form usually contains three kinds of activities:

1. INPUT; The program asks information, in our case INPUT is related to Digital and Analog signals;
2. CALCULATION and DECISION MAKING; The program transforms or manipulates the information;
3. OUTPUT; The program sets Digital or Analog OUTPUT signals to a particular value, PRINTs or SENDs an SMS message with the final result.

It is the programmer's job to determine exactly how to accomplish these steps.

12.3 VARIABLES - Doing something with information

In programming, you must assign each bit of data (or information) a unique name. This combination of a name or character is called a variable because the data part can vary each time the program use this variable. To calculate or manipulate Input- or Output-signals the I/O is linked to variables. Therefore the *M2M Control C10* has several predefined variables:

A ... Z	as integer, with in the range of: -32768 to +32767 After Power-Up, value = 0
EEA ... EEJ	NON VOLATILE integer, -32768+32767
DI1	for the digital input, value is 1 or 0 (ATTENTION!: read only)
DP1	Counter for the digital input, the value is 1 to 32767
DO1	for the digital output, value is 1 or 0
AI1	for the analog input, value is 0 to 1023 (ATTENTION!: read only)
TM1 ... TM8	for 100 milliseconds timer ATTENTION! if read, this variable returns 0, 1 or -1 Timer value can be set to 32767 max. this equals 3276,7 seconds
SEC	contains the number of seconds since the last minute lapse (0-59)
MIN	contains the number of minutes since the last hour lapse (0-59)
HRS	contains the number of hours since midnight (0-23)
DAY	contains the day of the month (1-31)
WDAY	contains the day of the week (0-6, 0=Sunday)
MTH	contains the month (1-12)
YRS	contains the number of years since 2000 (0-255)
TRE	(Time REsult) is 0 when the <i>M2M Control C100</i> thinks it has a valid time. It is 1 at bootup and becomes 0 when the <i>M2M Control C100</i> has successfully fetched the time from a time server or when the time is manually configured.

These Date & Time variables can't be written to by the BASIC program. However, they can be set using direct SET commands.

CTSM	Clear To SMs must be 1 before using the SMS command
CTSE	Clear To SEnd to see whether there is a working host link (0=no link available, 1=link available)
CTM	Clear To Mail must be 1 before using the MAIL command
MRE	Mail REsult, equals 0=ok, 1 indicates error, the mail was sent
SMRE	SMs REsult, 0=ok, 1 indicates error, SMS was not sent
SERE	SEnd REsult, 0=ok, 1 indicates error, SEND message was not sent

The data of variables are stored in RAM, this is the volatile Random Access Memory and data is lost after power down.

The BASIC program however is stored in FLASH (non-volatile) memory, a program remains in memory after power down.

Configuration and the variables EEA...EEJ are stored in EEPROM (non-volatile) memory, configuration settings and the variables EEA...EEJ remain in memory after power down.

12.4 OPERANDS – Doing some calculations

The *M2M Control C10* interpreter can manipulate variables with the following operands:
(assume variables with the following values: A=? or 2, B=5, C=3, D=10, E=1)

Sign	Name	How to use	Result
+	Plus (ADDITION)	A=B+C	8
-	Hyphen (SUBTRACTION)	A=B-C	2
*	Asterisk (MULTIPLICATION)	A=B*C	15
^	Circumflex (To the power of)	A=B^C	125
/	Slash (DEVISION)	A=B/C	1
%	Percent (MODULUS)	A=B%C	2
=	Equals sign	A=B	5
>	Greater-than sign	A>B	False
<	Less-than sign	A<B	True
&	Ampersand (AND bit wise)	A&B	0
	Vertical-line (OR bit wise)	A B	7

12.5 DELIMITERS – separating data

The interpreter can handle the following delimiters. These are used to separate parts of variables or instructions like:

;	SEMICOLON	used in statement X for next variable, PRINT "A=";A Result: ->A=2
,	COMMA	used in statement X as TAB between variables, PRINT A,B,C Result: ->2 5 3
()	PARENTHESIS	used in calculations, A = (C+B)*(D+E):PRINT A Result: (A=8 x 11 =) ->88
""	QUOTATION MARKS	used in statement X for TEXT to be printed, PRINT "A=";A
:	COLON	used for following statements, DO1=1:DO2=1:DO3=0

X represents: PRINT, SEND, LOG, EMAIL and SMS statement

12.6 AT FIRST – Doing something to start with

Now we have learned something about variables, calculations and delimiters, let's write a program with some of these items:

```
A=5:B=10:C=30
C=(A+B)*C
PRINT "C=";C
```

There is an easy way to load a short program, let's try it!

Type: **LOAD**<enter>

Answer: *Waiting for program or ESC.*

Type: **A=5:B=10:C=30** <enter>

Type: **C=(A+B)*C**<enter>

Type: **PRINT "C=";C**<enter>

Type: **#**<enter>

Answer: *Program Loaded. Type RUN to start.*

Let's check if you have made any typing errors before running it.

Type: **LIST**<enter>

```
Answer:      A=5 : B=10 : C=30
             C=(A+B)*C
             PRINT "C=" ; C
```

Type: **RUN**<enter>

```
Answer:      ->C=450
```

That's all you need to do to load this program and RUN it.

The result is: **->C=450** shown on your terminal screen.

This is a quick and easy method, however not suitable for large programs.


ATTENTION!

Since the <Back space> key does not work you can not correct typing mistakes. This is because the *M2M Control C10* program loader expects a correct file transferred in one piece from a computer.

12.7 GOTO - Doing something more than once

Assuming that the previous BASIC program does what we want, it still only does it once. Each time you want to use this little program you have to RUN it again. This is useless for a monitoring or control function. That's the reason why you will receive the warning that the program has stopped. What we need is a way for your program to go back to the beginning and do it over, and over again to monitor Input variables and Output results. In BASIC the command for doing this is called GOTO.

Knowing that we have to GOTO some place is not enough. We also need to know where to go. The mechanism that BASIC uses to mark places that we can go to is called a branch label. You mark the place in your BASIC program where you want it to continue running with a branch label using a line number. In principle you can freely use any number, however it makes sense to follow some rules for example: 10, 20, 30, . . . or 100, 200, 300, . . . max 99999. Maximum number of labels = 10.




ATTENTION!

For control and monitoring applications, this mechanism is most important. You should at all cost prevent that your program from getting in an undefined loop. Your program sequence should always continue to guarantee its proper working at all times. It is the programmer's skill that will accomplish this.

12.8 GOSUB - Doing some jump to a program part, do something and return

In the case that you would like to use some general program part from different part of your program you write a sub-routine. Use this from different parts and return to the next statement after the sub-routine called.

Example:



RETURN

Of course you can call a sub-routine from a sub-routine: in that case you can nest maximum 10 GOSUBs in GOSUBs.

12.9 IF...THEN...ELSE - Adding intelligence to your program

Your program usually needs to make some decisions at some points. Let's learn how to add some intelligence to your program. One way that this can be done is with the IF . . . THEN statement. For example:

```
IF DI1=1 THEN GOSUB 100
```

This program line lets you make a branch to the sub-routine at line 100 if Input 1 is ON.

Comparing numbers - The = (equal) operator is only one of several that can be used to make decisions in an IF . . . THEN statement. We can use the IF . . . THEN statement and the =, <>, <, > operators to determine whether:

```
a = b a is equal to b  
a <> b a is unequal to b  
a < b a is less than b  
a > b a is greater than b
```

As shown in the above example we use the IF . . . THEN statement in the same way for Input variables.

For example:

```
10 DO1=0  
IF DI1=1 THEN DO1=1  
GOTO 10  
#
```

In this case the output DO1 is set to 0 each time the program passes line 10 DO1=0 This will result in flickering, OFF...ON...OFF...ON...etc.

The ELSE statement gives the answer:

```
10 DO1=0  
20 IF DI1=1 THEN DO1=1 ELSE DO1=0  
GOTO 20  
#
```

The result of this program is a stable situation:

When Input 1 is ON then Output 1 is ON

When Input 1 is OFF then Output 1 is OFF

The first line (10) is used as an initialisation phase to guarantee a proper output state after power-up.

12.10 IF...AND/OR...THEN...ELSE - Adding more intelligence to your program

To check on one condition is usually not enough, the AND or OR statement gives the answer:

```
10 DO1=0  
20 IF DI1=1 AND DI2=1 THEN DO1=1 ELSE DO1=0  
GOTO 20  
#
```

Now we need to set 2 inputs to the ON position to set the output DO1 to ON.

12.11 More advance programming

For example:

```
10 DO1=0  
20 IF DI1=1 THEN DO1=1 ELSE DO1=0  
GOTO 20  
#
```

Same without IF

```
10 DO1=DI1  
GOTO 10  
#
```

For example:
10 DO1=0
20 IF DI1=1 OR DI2=1 THEN DO1=1 ELSE DO1=0
GOTO 20
#

Same without IF
10 DO1=DI1 OR DI2
GOTO 10
#

For example:
10 DO1=0
20 IF DI1=1 OR DI2=1 THEN GOSUB 100
GOTO 20
100 IF DI3=1 THEN DO1=1 ELSE DO1=0
#

Same without IF
10 DO1=DI3 AND (DI1 OR DI2)
GOTO 10
#

12.12 FOR...TO...NEXT - Adding loops to your program

In a for loop, we give a variable a value that it should start with. Then, we make it loop by incrementing this variable every time it runs through until it gets to a certain point. An example loop might look like this:

```
FOR I = 1 TO 10  
Something to do 10 times  
NEXT
```

In case we need to increase a variable with small equal steps, the FOR...NEXT loop is a handy way to do this. Assume we have a dimmer that uses 0-10 Vdc for 0 to 100% lighting level.

We can use the analog output to do the work. You would like to start the lamp smoothly after Input 1 is set to 1 for a short period (pulse), and dim back to off after Input 1 is pulsed to 1 again:

```
10 AO=0: A=0  
20 IF DI1=1 AND A=0 THEN GOSUB 100  
20 IF DI1=1 AND A=1 THEN GOSUB 200  
GOTO 20
```

```
100 A=1  
FOR I = 1 TO 100  
AO=I*10  
NEXT  
RETURN
```

```
200 A=0  
FOR J = 1 TO 100  
AO=AO-10  
NEXT  
RETURN  
#
```

This program expects a pulse on Input 1. At first it will change the analog output gradually from 0 to 10 volt. After the next pulse it will gradually decrease the output value from 10 to 0 volt. Of course you can have a FOR...NEXT in a FOR...NEXT, in that case you can nest maximum 10 FOR...NEXT's in a FOR...NEXT. An unwritten rule in BASIC is to use I and J in a FOR...NEXT.

ATTENTION: please note that the FOR...NEXT supports incrementing the loop variable only.

12.13 PRINT, SEND, LOG, MAIL and SMS - Informing the outside world

We talked about the PRINT statement. This is a very useful statement while testing or debugging your program. SEND does the same but not to the console port but to the internal modem. In other words it sends a PRINT command to some remote connection.

SMS does the same, but sends it out as an SMS to a mobile GSM cell phone.

The format is the same for all three commands.

```
PRINT "These are the results: A=";A,"B=";B,"C=";C
```

```
SEND "These are the results: A=";A,"B=";B,"C=";C
```

```
LOG "These are the results: A=";A,"B=";B,"C=";C
```

```
SMS 1,"These are the results: A=";A,"B=";B,"C=";C
```

```
MAIL 1,"These are the results: A=";A,"B=";B,"C=";C
```

Finally shown as:

These are the results: ->A=2 B=5 C=3

If you wonder to which GSM phone this message will be sent to, the telephone number is a part of the configuration parameters of the IO_10, see SET SMS....

12.14 REM - Adding remarks to your program

We often like to add some remarks to particular statements or program parts. The REM statement is very useful for this purpose.

Like this:

```
REM Dimmer program version 1.0
```

```
REM John Steed, 02-02-2003
```

```
10 A=0
```

```
20 IF DI1=1 AND A=0 THEN GOSUB 100
```

```
.....etc.
```

ATTENTION!

Do not use too many REM statements in your program since the total available memory is limited to 4 K bytes.

If you would like to comment on your program extensively do this in your source file after the # sign.

Like this:

```
.....
```

```
FOR I = 1 TO 100
```

```
10 A=A+10
```

```
NEXT I
```

```
RETURN
```

```
#
```

The following text explains the above program in detail.

At line 10 we increment the variable A by 10

The variable A is used as

Etc.. etc...

The # sign is used by the M2M Control C10 program loader as an end of program indicator. All text after the # sign is ignored and not stored in the program memory.

ATTENTION: while loading the program it can show some parts of the text; this is due to buffers that store blocks of text. Do LIST and you will see that it's OK.

12.15 FINAL - doing it more complex

So far, we explained a lot of different statements. A BASIC program will be a logical sequence of statements. It needs no explanation that we can do LOOPS in LOOPS for example:

```
FOR I = 1 TO 10
```

```
FOR J = 1 TO 10
```

```
AO=AO-10
```

```
NEXT
```


NEXT

You can nest maximum 10 LOOPS in LOOPS
Or we can do GOSUBs in GOSUBs, for example:

```
Do something...  
GOSUB 100
```

```
100  
Do something...  
GOSUB 200  
RETURN
```

You can nest maximum 10 GOSUBs in GOSUBs

ATTENTION!

Be aware not to use too many GOTO statements, it makes your program a mess and no one will understand the real workings.

12.16 COMMAND LINE MODE - doing something outside your program

Well, this was all about BASIC programming.

When you power-up your *M2M Control C10*, by default it will start to execute the program in memory. This is needed since the *M2M Control C10* is a monitoring and control module that has to do its job all the time. Just in case it becomes power less it should return to its normal operation mode as soon as the power returns.

However, when you have a Console connected to your *M2M Control C10* the program will NOT START and and wait for your commands.

To stop executing your program, type: **STOP** <enter>
The *M2M Control C10* will go into the Command Line mode.
In this mode you have full control over all outputs.

ATTENTION!

Be sure that you know what outputs do before switching something ON!

Please read chapter 7 to understand the "Command line mode" commands in detail.
Since we talked about BASIC programming in this chapter we like to mention some handy "Command line mode" commands to use during programming.

- **LOAD** a basic program into the non-volatile memory of the module, max. 4096 characters of program text.
- **LIST** the internal basic program.
- **RUN** the internal basic program starting at the first line.
- **STOP** the internal basic program.
- **CONT** continue execution at the position the program was stopped.
- **HELP** shows initial instructions.
- **STEP** step 1 line used for debugging, each executed line is printed on the terminal.
- **RESET** start from first line.

We wish you happy programming and a fast start. Many demonstration programs are available to give you a better understanding of the *M2M Control C10* and the BASIC interpreter.
Good Luck!

Please mail your comments to: info@m2mcontrol.de.

13 APPENDIX

13.1 GSM Modem states

In order to see what the modem is doing the user can turn ON the verbose mode type:

MODEMVERBOSE 1

This will result in modem state numbers on the console port. Below a list of the state numbers:

Because of a review of the library handling the modem communication there has been a change in the states and substates reported by the M2M Control module when MODEMVERBOSE is set.

Modem states

0: STATE_INIT	- The M2M Control is initializing the modem
1: STATE_IDLE	- The modem is initialized and the module is able to send SMS's and to receive incoming calls
2: STATE_DIAL	- Not used yet (for dialing out)
3: STATE_DATA_OUT	- Not used yet (dial out connection established)
4: STATE_ANSWER	- Answering incoming call
5: STATE_DATA_IN	- Incoming call established
6: STATE_DIAL_TCP	- Not used yet (for setting up TCP connection)
7: STATE_TCP_OUT	- Not used yet (TCP out connection established)
8: STATE_DISCONNECT	- Remote disconnected, or problems trying to connect
9: STATE_SPECIALS_START	- Not used as real state, only as reference
10: STATE_OPERATOR	- Requesting the GSM operator
11: STATE_RSSI	- Requesting the signal strength

Modem substates

0: SUBSTATE_INIT_NO_MODEM	- No modem detected (default startup state)
1: SUBSTATE_INIT_TELIT_MODEM	- Check if modem is ON
2: SUBSTATE_INIT_TELIT_PULSE_WAIT	- Wait for modem to switch ON
3: SUBSTATE_INIT_TELIT_SEARCH	- Search the modem
4: SUBSTATE_INIT_MODEM_DETECTED	- A modem is detected
5: SUBSTATE_INIT_ESCAPE1	- Delay for escape command
6: SUBSTATE_INIT_ESCAPE2	- Send escape command
7: SUBSTATE_INIT_STRING	- Send the initialization string
8: SUBSTATE_INIT_PIN_GET	- Request PIN status
9: SUBSTATE_INIT_EXPECT_PIN_GET	- Wait for PIN_GET response
10: SUBSTATE_INIT_SIM_PIN	- SIM expects PIN
11: SUBSTATE_INIT_EXPECT_PIN_RESULT	- PIN sent, wait for response
12: SUBSTATE_INIT_SIM_ERROR	- Problems with SIM: not there, defect
13: SUBSTATE_INIT_PIN_ERROR	- Error, probably wrong PIN
14: SUBSTATE_INIT_SIM_PUK	- SIM needs PUK code (put SIM in cellphone to handle this, can not be done out of M2M Control)
15: SUBSTATE_INIT_SIM_OK	- PIN accepted
16: SUBSTATE_INIT_CHECK_SIM_READY	- Wait until the SIM is ready to communicate with (called repeatedly at powerup)
17: SUBSTATE_INIT_CHECK_NETWORK_READY	- Check if SIM is registered to an operator.
18: SUBSTATE_INIT_SET_FORMAT	- Set SMS format to text
19: SUBSTATE_INIT_WAIT_FORMAT_OK	- Wait for SMS format accepted
20: SUBSTATE_INIT_SET_SMS_INDICATION	- Let modem indicate the reception of a new SMS
21: SUBSTATE_INIT_SMS_INDICATION_OK	- Wait for acceptance of SMS indication
22: SUBSTATE_INIT_TX_BUF_FULL	- Sending command to modem not possible
23: SUBSTATE_INIT_TIMER_EXPIRED	- Answer from modem took too long

24..38: Free space for future initialization states

39: SUBSTATE_IDLE	- Modem ready to send and receive
40: SUBSTATE_SMS_WAIT_SMS_PROMPT	- Wait for SMS prompt
41: SUBSTATE_SMS_SEND	- Sending an SMS
42: SUBSTATE_SMS_WAIT_OK	- Wait for sending SMS OK
43: SUBSTATE_SMS_TX_BUF_FULL	- Sending SMS to modem not possible
44: SUBSTATE_SMS_TIMER_EXPIRED	- Answer from modem took too long (possible GPRS only SIM)
45: SUBSTATE_SMS_WAIT_BUFFER_EMPTY	- Wait until all data to modem is sent
46: SUBSTATE_SMS_ESCAPE1	- Delay for escape command
47: SUBSTATE_SMS_ESCAPE2	- Send escape command
48: SUBSTATE_SMS_ESCAPED	- Switched from data to text mode
49: SUBSTATE_SMS_RETURN_DATA	- Return from text to data mode
50: SUBSTATE_SMS_WAIT_RETURN_OK	- Wait for returning to data mode OK
51: SUBSTATE_SMS_EXPECT_SMS	- Expect SMS from modem
52: SUBSTATE_SMS_GET_DATA	- Retrieve relevant data from SMS
53: SUBSTATE_SMS_DEL_SMS	- Delete the SMS from the SIM

54..69 Free space for future SMS states

70: SUBSTATE_WAIT_CONNECT	- Wait for the CONNECT string to receive
71: SUBSTATE_WAIT_NO_CARRIER	- Wait for NO CARRIER text while disconnecting

72..79 Free space for dial-in/dial-out states

80: SUBSTATE_OPERATOR	- Request the operator
81: SUBSTATE_EXPECT_OPERATOR	- Expect the operator
82: SUBSTATE_OPERATOR_TIMER_EXPIRED	- Answer from modem took too long
83: SUBSTATE_RSSI	- Request the signal strength
84: SUBSTATE_EXPECT_RSSI	- Expect the signal strength
85: SUBSTATE_RSSI_TIMER_EXPIRED	- Answer from modem took too long

86..99 Free space for future special states

100: SUBSTATE_GPRS_SET_CONTEXT	- Set the GPRS context parameters
101: SUBSTATE_GPRS_SET_SMTP	- Set the SMTP(mail)server for sending emails
102: SUBSTATE_GPRS_SET_MAILUSER	- Set username for mailserver
103: SUBSTATE_GPRS_SET_MAILPASS	- Set password for mailserver
104: SUBSTATE_GPRS_SET_FROM	- Set sender of the mail
105: SUBSTATE_GPRS_SET_USER	- Set the username for if connecting to the GPRS network requires one
106: SUBSTATE_GPRS_SET_PASS	- Set the corresponding password for if connecting to the GPRS network requires one
107: SUBSTATE_GPRS_SET_SOCKET	- Set the remote socket to connect to
108: SUBSTATE_GPRS_OPEN_SOCKET	- Open the socket, that is, make a connection to the configured host on the configured port
109: SUBSTATE_GPRS_WAIT_CONNECT	- Wait for the connection to be established
110: SUBSTATE_GPRS_DELAY_CONNECT	- Delay a short time before reconnecting. This requires the modem

111..129 Free space for future GPRS initialisation states

130(-126): SUBSTATE_GPRS_SEND_EMAIL	- Send an email
131(-125): SUBSTATE_GPRS_WAIT_MAIL_PROMPT	- Wait for the mail prompt
132(-124): SUBSTATE_GPRS_WAIT_MAIL_OK	- Wait for OK after sending the email
133(-123): SUBSTATE_GPRS_MAIL_TIMER_EXPIRED	- Answer from modem took too long
134(-122): SUBSTATE_GPRS_MAIL_WAIT_BUFFER_EMPTY	- Wait for an empty serial

- 135(-121): SUBSTATE_GPRS_MAIL_DELAY - buffer before closing the GPRS link
- 136(-120): SUBSTATE_GPRS_MAIL_CLOSE - Delay a required time before sending the connection close command
- 137(-119): SUBSTATE_GPRS_MAIL_CLOSED - Close the connection
- Connection closed for sending mail. This state indicates that after sending the mail, the GPRS connection must be re-established

(-)The negative values are printed as well, because the first versions of the M2M Control suffered a signed/unsigned bug for printing the states.

SMS states

- 0: HTMODEM_SMS_STATE_INIT - The M2M Control is initializing the modem
- 1: HTMODEM_SMS_STATE_IDLE - Modem ready to send SMS's
- 2: HTMODEM_SMS_STATE_WAIT_SEND - SMS ready to be sent
- 3: HTMODEM_SMS_STATE_WAIT_RECEIVE - Request for reading SMS pending
- 4: HTMODEM_SMS_STATE_WAIT_POLL - Not used yet (for polling incoming SMS's)
- 5: HTMODEM_SMS_STATE_ESCAPE_SEND - Escape from data to text mode for sending SMS
- 6: HTMODEM_SMS_STATE_ESCAPE_POLL - Not used yet (for escaping to poll incoming SMS's)
- 7: HTMODEM_SMS_STATE_SEND - Modem is sending an SMS
- 8: HTMODEM_SMS_STATE_RECEIVE - Read SMS from SIM
- 9: HTMODEM_SMS_STATE_POLL - Not used yet (For modem is polling incoming SMS's)
- 10: HTMODEM_SMS_STATE_RETURN_DATA - Return from text to data mode

Email states

- 0: HTMODEM_MAIL_STATE_INIT - The M2M Control is initializing the modem
- 1: HTMODEM_MAIL_STATE_IDLE - Modem ready to send emails
- 2: HTMODEM_MAIL_STATE_WAIT_SEND - Email ready to be sent
- 3: HTMODEM_MAIL_STATE_ESCAPE_SEND - Close GPRS link before sending email
- 4: HTMODEM_MAIL_STATE_DISCONNECT - Close GPRS link
- 5: HTMODEM_MAIL_STATE_SEND - Send the email coming from IDLE state
- 6: HTMODEM_MAIL_STATE_SEND_CLOSED - Send the email coming from TCP_OUT state

Turn OFF the verbose mode type: **MODEMVERBOSE 0**

13.2 Configuration HINTS

For use of GPRS

General settings:

- SET APN, like "Internet"
 - SET TCPSUSER ¹⁾
 - SET TCPSPASS ¹⁾
 - TCP ON ²⁾
- ¹⁾ Use when specified by Telco for authentication

For use of E-MAIL function only

- General settings
- SET MAILUSER ³⁾
- SET MAILPASS ³⁾
- SET SMTP ⁴⁾
- SET HOST = 0 ⁵⁾
- SET PORT = 0 ⁵⁾

²⁾ Only if you use SENT command (link with HOST)

³⁾ Check with Telco or Mail Server owner for details

⁴⁾ Be sure to use the correct name e.g.: In Germany not smtp.vodafone.de but authsmtp.vodafone.de

⁵⁾ One or both should be 0

Please check the CTM (Clear To Mail) variable for 1 before sending an e-mail message. In case your mail does not get through, we advise to fill the FROM field with a@SMTP Server domain name. Like: M2M@vodafone.de
This is because some mail servers either use User/Password or check domain extension.

For use of GPRS LINK

- General settings
- SET HOST = IP address or URL of HOST
- SET PORT = Port address of port used on HOST

The GPRS link can only be used when suitable software is running on the specified host, listening to the specified port. (M2M Control will release sample software (VB6 source) soon)

For use of E-MAIL function + GPRS LINK

- General settings
- SET MAILUSER
- SET MAILPASS
- SET SMTP
- SET HOST = IP address or URL of HOST
- SET PORT = Port address of port used on HOST

M2M Control is a trade name of

Infranet Technologies GmbH

Tempowerkring 2

21079 Hamburg - Germany

tel. +49 (0)40 696 47 – 260 fax +49 (0)40 696 47 – 259

E-Mail: info@m2mcontrol.de Web: www.m2mcontrol.de